

Dark spots / loose clips behind the screen

1. Remove the lamp from the ceiling.
2. Place the lamp on a flat surface.
3. The back plate can now be loosened using a screwdriver, the screwdriver must go down between the back plate and the edge of the lamp.
4. Place something between the edge of the lamp and the screwdriver to prevent the lamp from getting scratched.
5. The loose clips can now be reassembled and the lamp can be assembled.
6. Mount the lamp on the ceiling without pressing on the screen.

Press only on the aluminum edge of the lamp!

Mørke pletter/løse klips bag skærm

1. Afmontere lampen fra loftet.
2. Læg lampen på et fladt underlag.
3. Bagpladen kan nu løsnes ved hjælp af en skruetrækker, skruetrækkeren skal ned mellem bagplade og kanten på lampen.
4. Læg noget imellem lampens kant og skruetrækker, for at undgå lampen får ridser.
5. De løse klips kan nu monteres igen og lampen kan samles.
6. Monter lampen på loftet igen uden at trykke på skærmen. **Tryk kun på lampens aluminiumskant!**

